



BW236 programming user guide

Release 5.3.2

Table of contents

1	Introduction	1
1.1	Description	1
1.2	Module Default Settings	1
2	Hardware Description	2
2.1	Pin Figure	2
2.2	Pin Description	3
2.3	Hardware Design Notes	3
3	Function Description	4
3.1	Hardware Interface	4
3.2	Bluetooth	4
3.3	Wi-Fi	4
4	Command Description	6
4.1	Specification	6
4.2	Command Format	6
4.3	Event Format	7
5	Commands Table	9
5.1	General Commands	9
5.1.1	AT - UART Test Command	9
5.1.2	AT+VER - Read Firmware Version	9
5.1.3	AT+BAUD - Read/Write UART Baudrate	10
5.1.4	AT+TPMODE - Read/Write Throughput Mode	11
5.1.5	AT+LPM - Enter Low Power Mode	12
5.1.6	AT+SCAN - Scan Devices	13
5.1.7	AT+REBOOT - Software Reset	15
5.1.8	AT+RESTORE - Restore Factory Setting	16
5.1.9	AT+BTEN - Enable/Disable Bluetooth	16

5.1.10	AT+STAT - Read Connection Status	17
5.1.11	AT+DSCA - Disconnect From AP or BLE Device	18
5.2	Bluetooth Command	18
5.2.1	AT+ADDR/LEADDR - Read Bluetooth MAC	18
5.2.2	AT+NAME/LENAM - Read/Write Bluetooth BLE Name	19
5.2.3	AT+GATTSEND - Send BLE Data in Peripheral Mode	20
5.2.4	AT+MODE: Read/Write Bluetooth Mode	20
5.2.5	AT+LECONN - Connect to Remote BLE Device in Central Mode	21
5.2.6	AT+GATTAC - Read/Write Auto Connection Setting in BLE Central Mode	21
5.2.7	AT+LESEND - Send Data in BLE Central Mode	22
5.2.8	AT+GATTSTAT - Read Connection Status	22
5.2.9	AT+TYPE - Read/Write BLE Connection Type	23
5.2.10	AT+PIN - Read/Write Bluetooth BLE PIN Code	23
5.3	Wi-Fi Command	24
5.3.1	AT+ROLE - Read/Write Wi-Fi Mode	24
5.3.2	AT+RAP - Read Connected AP' s information/Connect to Remote AP	25
5.3.3	AT+BRAP - Connect to AP by BSSID	26
5.3.4	AT+CAP - Clear Connected AP' s Information	27
5.3.5	AT+BSSID - Read Connected AP' s BSSID	27
5.3.6	AT+LIP - Read Current Local IP Address	28
5.3.7	AT+MDNSEN - Enable/Disable MDNS Function	28
5.3.8	AT+DHCP - Read/Write IP Distribution Mode	29
5.3.9	AT+SIP - Read/Write Static IP	29
5.3.10	AT+GW - Read/Write Gateway	30
5.3.11	AT+MASK - Read/Write Subnet Mask	31
5.3.12	AT+DNS - Read/Write DNS Address	31
5.3.13	AT+APAC - Read/Write Automatically Connect to AP	32
5.3.14	AT+RSSI - Read Signal Strength Between Module And AP	32
5.3.15	AT+STAMP - Read Time Stamp	33
5.3.16	AT+MAC - Read Wi-Fi MAC Address	33
5.3.17	AT+SCFG - Simple Config	34
5.3.18	AT+WEBCFG - WEB Config	34
5.3.19	AT+WPSCFG - WPS Config	35
5.3.20	AT+LAP - Read/Write AP Mode Configuration	35
5.4	TCP Command	36
5.4.1	AT+SOCK - Read/Write SOCKET	36

5.4.2	AT+WLANC - Start SOCKET/MQTT	37
5.4.3	AT+MAXCON - Read/Write Max Connections As TCP Server	37
5.4.4	AT+WFSEND - Send SOCKET Data to Remote Device	38
5.4.5	AT+CLOSE - Close Connection as TCP client	39
5.5	WEBSOCKET Command	39
5.5.1	AT+WEBSOCK - Read/Write WEBSOCKET Address	40
5.5.2	AT+WSEND - Send Websocket Data	41
5.5.3	AT+WSCLS - Close Websocket	41
5.5.4	AT+WSSTAT - Read Websocket Status	42
5.6	HTTP Command	42
5.6.1	AT+HTTP - Access the HTTP Server	43
5.7	MQTT Command	44
5.7.1	AT+BROKER - Read/Write MQTT broker	44
5.7.2	AT+CLIENTID - Read/Write MQTT Client ID	45
5.7.3	AT+USERNAME - Read/Write MQTT USERNAME	45
5.7.4	AT+MQTTPWD - Read/Write MQTT password	46
5.7.5	AT+SUBTPC - Read/Subscribe MQTT Topic	46
5.7.6	AT+UNSUBTPC - Unsubscribe Specify MQTT Topic	47
5.7.7	AT+UNSUBALL - Unsubscribe All MQTT Topics	48
5.7.8	AT+MQTTSEND - Send MQTT Data	48
5.7.9	AT+MQTTMODE - Read/Write MQTT Mode	49
5.7.10	AT+MQTTSSL - Enable/Disable MQTT with SSL/TLS	49
5.7.11	AT+MQTTPORT - Read/Write MQTT Port	50
5.7.12	AT+MQTTKAI - Read/Write MQTT Keepalive	50
5.7.13	AT+MQTTVER - Read/Write MQTT Version	51
5.7.14	AT+MQTTCLS - Close MQTT Connection	52
5.8	Cloud Platform Command	52
5.8.1	AT+DEVNAME - Read/Write Device Name	52
5.8.2	AT+PROKEY - Read/Write Product Key	53
5.8.3	AT+DEVSECRET - Read/Write Device Secret	53
5.9	EAP Command	54
5.9.1	AT+EAPEN - Read/Write EAP enterprise encryption	54
5.9.2	AT+EAPMODE - Read/Write EAP encryption	54
5.9.3	AT+EAPCFG - Read/Write EAP connection parameters	55
5.10	The Firmware Update(OTA)	55
5.10.1	AT+OTA - Remote OTA	55

6	Events Table	57
6.1	MQTT Indication	57
6.1.1	+MQTTSTAT - MQTT Status	57
6.1.2	+MQTTDATA - MQTT Received Data	57
6.2	WEBSOCKET Indication	58
6.2.1	+WSSTAT - WEBSOCKET 状态	58
6.3	SSL Indication	58
6.3.1	+SSLSTAT - SSL Client Status	59
6.3.2	+SSLDATA - Receive SSL Data	59
6.4	SOCKET Indication	59
6.4.1	+WFDATA - Receive SOCKET Data	59
6.5	GATT Indication	60
6.5.1	+GATTSTAT - GATT Status	60
6.5.2	+GATTDATA - Receive GATT Data	60
7	Application Scenarios	61
7.1	TCP Server Application	62
7.2	TCP Client Application	64
7.3	UDP Application	66
7.4	MQTT Application	69
7.5	Ali Cloud Platform Application	72
7.6	Switch Throughput Mode to Command Mode	74
7.7	Network Configuration and OTA	75
7.7.1	OTA by AT Command	75
7.7.2	OTA by FeasyWiFi APP	76
8	Appendix	84
8.1	Download PDF Document	84

Chapter 1

Introduction

[中文]

1.1 Description


This design guide is suitable for engineers to develop FSC-BW236 Wi-Fi SoC module

1.2 Module Default Settings

Bluetooth Mode	LE-Peripheral
Bluetooth Name	FSC-BW236-LE
Wi-Fi Mode	STA Mode
Local AP SSID	FSC-BW236-AP
Local AP Password	12345678
Local AP IP Address	192.168.1.1
UART Baudrate	115200/8/N/1

Hardware Description

2.1 Pin Figure



2.2 Pin Description

Pin	Pin Name	Type	Pin Descriptions
1	UART_TX	O	UART TX
2	UART_RX	I	UART RX
3	UART_CTS	I	UART CTS(Active High)
4	UART_RTS	O	UART RTS(Active High)
9	UARG_LOG_OUT	O	DEBUG UART TX
10	UARG_LOG_IN	I	DEBUG UART RX
11	RESET/CHIP_EN	I/O	RESET, Active Low
12	VDD_3V3	VDD	3.3V Power Supply
13	GND	VSS	GND
21	GND	VSS	GND
22	GND	VSS	GND
32	LED0	I/O	Output High Level When Bluetooth Connected
33	LED1	I/O	Output High Level When Wi-Fi Connected
35	GND	VSS	GND
36	EXT_ANT	ANT	Antenna Option

2.3 Hardware Design Notes

- Module only needs to connect VDD/GND/UART_RX/UART_TX for a simple test
- Programming manual only provides a simple description of the IO port. For more detailed description, please refer to the hardware design document
- Feasycom is glad to review your schematic diagram for a best result of Bluetooth/Wi-Fi distance

Chapter 3

Function Description

3.1 Hardware Interface

- GPIO
- PWM
- UART
- SPI SLAVE
- I2S Master/Slave
- Analog Input/Output

Profiles & Features

3.2 Bluetooth

- GATTS (Generic Attribute Profile LE-Peripheral role)
- GATTC (Generic Attribute Profile LE-Central role)

3.3 Wi-Fi

- TCP (Transmission Control Protocol)
- UDP (USER Datagram Protocol)

- HTTP (Hypertext Transfer Protocol)
- MQTT (Message Queuing Telemetry Transport)
- WEB SOCKET

Shenzhen Feasycom Co., Ltd.

Chapter 4

Command Description

4.1 Specification

- {} : Content between {} is optional
- << : Content behind << represents a **COMMAND** from Host
- >> : Content behind >> represents a **RESPONSE/EVENT** to Host

4.2 Command Format

AT+Command{=Param1{Param2{Param3...}}}<CR><LF>

- All commands start with “AT” , end with <CR><LF>
- <CR> means “carriage return” , corresponds to hex value 0x0D
- <LF> means “line feed” , corresponds to hex value 0x0A
- If Command has Parameter, Parameter follows behind ‘=’
- If Command has multiple Parameters, Parameter must be separated by ‘,’
- If Command has Response, Response starts with <CR><LF>, ends with <CR><LF>
- Module will always report command’ s execution result by using **OK** for success or **ERR<code>** for failure

Error Code	Meaning
001	Failed
002	Invalid parameter
003	Invalid state
004	Command mismatch
005	Busy
006	Command not supported
007	Profile not turned on
008	No memory
Others	Reserved for future use

Example:

Read Module' s Version

<< AT+VER

>> +VER=FSC-BW236,V4.2.5

>> OK

Send Bluetooth Data When Disconnected

<< AT+GATTSEND=3,123

>> ERR003

4.3 Event Format

<CR><LF>+Indication{=Param1{,Param2{,Param3...}}}<CR><LF>

- All Events start with <CR><LF>, end with <CR><LF>
- If Event has Parameter, Parameter follow behind '='
- If Event has multiple Parameters, Parameter must be separated by ','

‘Example:’

Remote BLE Device Send “1234567890” to Module

>> +GATTDATA=10,1234567890

Shenzhen Feasycom Co., Ltd.

Chapter 5

Commands Table

5.1 General Commands

5.1.1 AT - UART Test Command

Command	AT
Response	OK
Description	Test whether the UART is working

Example:

<< AT

>> OK

5.1.2 AT+VER - Read Firmware Version

Command	AT+VER
Response	+VER=Param1,Param2
Param1	Module Type
Param2	Firmware Version

Example:

<< AT+VER

>> +VER=FSC-BW236,V4.2.5

>> OK

5.1.3 AT+BAUD - Read/Write UART Baudrate

Command	AT+BAUD{=Param}
Param	2400/4800/9600/19200/38400/57600/115200(default)/128000/ 230400/256000/460800/512000/921600/1000000/1382400 2000000/3000000/4000000/5000000/6000000
Response	+BAUD=Param
Param	All baudrates supported by current module
Description	Baudrate will be changed after module reboot

Example:

Read Baudrate

<< AT+BAUD

>> +BAUD=115200

>> OK

Write Baudrate

<< AT+BAUD=9600

>> OK

5.1.4 AT+TPMODE - Read/Write Throughput Mode

Command	AT+TPMODE{=Param}
Param	1:Enable 0:Disable
Response	+TPMODE=Param
Param	Module' s current throughput mode
Description	When TCP/GATT profile connected and throughput mode is on, the AT command will be de-active, every byte received via physical UART will be sent to air, vice versa

Example:

Read Current Throughput Mode

<< AT+TPMODE

>> +TPMODE=0

>> OK

Enable Throughput Mode

<< AT+TPMODE=1

>> OK

5.1.5 AT+LPM - Enter Low Power Mode

Command	AT+LPM{=Param}
Param	1:Enter Light Sleep 2:Enter Deep Sleep
Response	OK
Description	After module enters lighth sleep, it maintains connection with the hotspot and TCP, and can be waked up through WLAN RX data. The power consumption is about 30mA. After module enters deep sleep, all functions will be stopped and the power consumption is about 10uA. Pull up the 7th pin of the module to wake up.

Example:

Enter Light Sleep

<< AT+LPM=1

>> OK

5.1.6 AT+SCAN - Scan Devices

Command	AT+SCAN=Param1{,Param2}{,Param3}
Param1	5:Scan AP around 1:Scan BLE devices 0:Stop Scanning
Param2	Only take effect when scanning BLE devices scan duration (unit: second) is specified After a timeout, module stops scanning
Param3	Only take effect when scanning BLE devices BLE device' s name is specified After a timeout, module stops scanning

Response	+SCAN=param1,param2,param3,param4,param5,param6
Param1	Scan AP: Sequence Numbers Scan BLE device: Sequence Numbers
Param2	Scan AP: 5(changeless) Scan BLE device:BLE device address type
Param3	Scan AP: AP' s MAC address Scan BLE device: BLE device' s MAC address
Param4	Scan AP: RSSI for module and AP Scan BLE device: RSSI for module and BLE device
Param5	Scan AP: Length of AP' s SSID Scan BLE device: Length of BLE device' s name
Param6	Scan AP: AP' s SSID Scan BLE device:BLE device' s name
Description	Scan AP: in STA Mode Scan BLE device:in Central Mode

Example:

Scan AP

```
<< AT+SCAN=5
```

```
>> +SCAN=1,5,9C9D7E7E0AF3,-45,18,Feasycom_D710_2.4G
```

```
>> +SCAN=2,5,9C9D7E7E0AF2,-47,16,Feasycom_D710_5G
```

```
>> +SCAN=3,5,D4DA210B8505,-50,13,Redmi_8502_5G
```

Scan BLE devices

```
<< AT+SCAN=1
```

```
>> +SCAN=1,0,DC0D94B9105C,-92,8,Feasycom
```

```
>> +SCAN=2,1,27AD5E8F09D6,-66,9,Feasycom1
```

```
>> +SCAN=3,0,DC0D300005B4,-82,9,Feasycom2
```

```
>> +SCAN=4,0,DC0D1EDA2008,-92,9,Feasycom3
```

Scan Specified BLE Device For 10s

```
<< AT+SCAN=1,10,FSC-BT976
```

```
>> +SCAN=1,0,DC0D3000073D,-66,9,FSC-BT976
```

5.1.7 AT+REBOOT - Software Reset

Command	AT+REBOOT
Response	OK
Description	Module Reboot

Example:

```
<< AT+REBOOT
```

```
>> OK
```

5.1.8 AT+RESTORE - Restore Factory Setting

Command	AT+RESTORE
Response	OK
Description	Module restore all factory settings then reboot

Example:

<< AT+RESTORE

>> OK

5.1.9 AT+BTEN - Enable/Disable Bluetooth

Command	AT+BTEN{=Param}
Param	1: Enable 0: Disable
Description	Only take effect immediately

5.1.10 AT+STAT - Read Connection Status

Command	AT+STAT
Response	+STAT=Param1, Param2, Param3, Param4, Param5, Param6, Param7
Param1	Connection Status in BLE Peripheral Mode
Param2	Connection Status in BLE Central Mode
Param3	Connection Status to Access Point
Param4	Connection Status as Tcp Server
Param5	Connection Status as Tcp Client
Param6	Connection Status as SSL client
Param7	Connection Status as MQTT client
Description	0: uninitialized 1: ready 2: connecting 3: connected

Example:Read Current Status

<< AT+STAT

>> +STAT=0,1,3,1,0,0,0

>> OK

5.1.11 AT+DSCA - Disconnect From AP or BLE Device

Command	AT+DSCA=Param
Param	1:Disconnect the module from the AP 2:Disconnect the module from the BLE device
Response	OK
Description	Command can be used only in STA mode or Peripheral mode.

Example:

Disconnect the module from the AP

```
<< AT+DSCA=1
```

```
>> OK
```

Disconnect the module from the BLE device

```
<< AT+DSCA=2
```

```
>> OK
```

5.2 Bluetooth Command

5.2.1 AT+ADDR/LEADDR - Read Bluetooth MAC

Command	AT+ADDR/LEADDR
Response	+ADDR/LEADDR=Param
Param	Module' s LE MAC address (12 Bytes ASCII)
Description	Only Read Supported

Example:

```
<< AT+ADDR/LEADDR
```

```
>> +ADDR/LEADDR=DC0D30010203
```

>> OK

5.2.2 AT+NAME/LENNAME - Read/Write Bluetooth BLE Name

Command	AT+NAME/LENNAME{=Param1{,Param2}}
Param1	BLE local name(1~25 Bytes ASCII)
Param2	MAC address suffix(0/1,default:1) 0-Disable suffix 1-Enable suffix “-XXXX” (lower 4 bytes of MAC address) after local name
Response	+NAME/LENNAME=Param
Description	

Example:

Read Bluetooth BLE Name

```
<< AT+NAME/LENNAME
```

```
>> +NAME/LENNAME=FSC-BW236-XXXX
```

```
>> OK
```

Write Bluetooth BLE Name as “ABC”

```
<< AT+NAME/LENNAME=ABC,0
```

```
>> OK
```

Write Bluetooth BLE Name as “ABC” and add MAC address suffix

```
<< AT+NAME/LENNAME=ABC,1
```

```
>> OK
```

5.2.3 AT+GATTSEND - Send BLE Data in Peripheral Mode

Command	AT+GATTSEND=Param1,Param2
Param1	Payload length (1~999)
Param2	Payload (1~999 Bytes UTF8)
Response	OK
Description	If throughput mode is enable, this command is de-active

Example:

Send “123” to remote BLE Device

```
<< AT+GATTSEND=3,123
```

```
>> OK
```

5.2.4 AT+MODE: Read/Write Bluetooth Mode

Command	AT+MODE{=Param}
Param	0: BLE Peripheral 1: BLE Central
Response	+MODE=Param
Description	Module will reboot after setting

Example:

Read Current Bluetooth Mode

```
<< AT+MODE
```

```
>> +MODE=0
```

```
>> OK
```

Write BLE Central Mode

```
<< AT+MODE=1
```

>> OK

5.2.5 AT+LECONN - Connect to Remote BLE Device in Central Mode

Command	AT+LECONN=Param1,Param2
Param1	BLE device' s MAC address type(0:public,1:random)
Param2	BLE device' s MAC address
Response	OK
Description	Only take effect in BLE Central Mode

Example:

Connect to Remote Device

<< AT+LECONN=0,DC0D30600002

>> OK

5.2.6 AT+GATTAC - Read/Write Auto Connection Setting in BLE Central Mode

Command	AT+GATTAC{=Param}
Param	0: Disable 1: Enable(default)
Response	+GATTAC=Param
Description	Only take effect after reboot

Example:

Read Whether Auto Connection Setting is Enabled

<< AT+GATTAC

```
>> +GATTAC=1
```

```
>> OK
```

Disable Auto Connection Function

```
<< AT+GATTAC=0
```

```
>> OK
```

5.2.7 AT+LESEND - Send Data in BLE Central Mode

Command	AT+LESEND=Param1,Param2
Param1	Payload length (1~999)
Param2	Payload (1~999 Bytes UTF8)
Response	OK
Description	If throughput mode is enable, this command is de-active

Example:

```
<<AT+LESEND=10,1234567890
```

```
>> OK
```

5.2.8 AT+GATTSTAT - Read Connection Status

Command	AT+GATTSTAT
Response	+GATTSTAT=Param1
Param1	Connection Status in BLE Peripheral/Central Mode
Description	0: uninitialized 1: ready 2: connecting 3: connected

5.2.9 AT+TYPE - Read/Write BLE Connection Type

Command	AT+TYPE{=Param}
Param	0:Unbound 1:Binding without PIN code 2:Binding with PIN code
Response	+TYPE=Param
Param	Module' s GATT connection type

5.2.10 AT+PIN - Read/Write Bluetooth BLE PIN Code

Command	AT+PIN{=Param1}
Param1	BLE local PIN Code(32 - bit unsigned integer number)
Response	+PIN=Param
Description	

Example:

Read Bluetooth PIN Code

<< AT+PIN

>> +PIN=123456

>> OK

Write Bluetooth PIN Code as “996”

<< AT+PIN=996

>> OK

5.3 Wi-Fi Command

5.3.1 AT+ROLE - Read/Write Wi-Fi Mode

Command	AT+ROLE{=Param}
Param	1:STA Mode 2:AP Mode 3:STA+AP Concurrent Mode
Response	+ROLE=Param
Description	Module will reboot after setting

Example:

Read Current Wi-Fi Mode

<< AT+ROLE

>> +ROLE=1

>> OK

Write AP Mode

<< AT+ROLE=2

>> OK

5.3.2 AT+RAP - Read Connected AP' s information/Connect to Remote AP

Command	AT+RAP{=Param1}{,Param2}
Param1	AP' s SSID
Param2	AP' s password,if way of encryption is OPEN, no need to set this parameter
Response	+RAP=Param1,Param2
Description	This command can be used in STA mode or STA+AP concurrent mode Module adapts different encryption ways automatically

Example:

Connect to AP named “test” ,and AP' s password is “12345678”

```
<< AT+RAP=test,12345678
```

```
>> OK
```

Read Current Connected AP' s Information

```
<< AT+RAP
```

```
>> +RAP=test,12345678
```

```
>> OK
```

Connect AP named “test” ,and AP' s encryption way is OPEN

```
<< AT+RAP=test
```

```
>> OK
```

5.3.3 AT+BRAP - Connect to AP by BSSID

Command	AT+BRAP{=Param1}{,Param2}
Param1	AP' s BSSID(MAC address)
Param2	AP' s password,if way of encryption is OPEN, no need to set this parameter
Response	+BRAP=Param1,Param2
Description	This command can be used in STA mode or STA+AP concurrent mode Module adapts different encryption ways automatically

Example:

AP' s BSSID is “1063C85FCB9F” ,and AP' Password is “12345678”

<< AT+BRAP=1063C85FCB9F,12345678

>> OK

Read Current Connected AP' s Information

<< AT+BRAP

>> +BRAP=1063C85FCB9F,12345678

>> OK

AP' s BSSID is “1063C85FCB9F” ,and AP' s encryption way is OPEN

<< AT+BRAP=1063C85FCB9F

>> OK

5.3.4 AT+CAP - Clear Connected AP' s Information

Command	AT+CAP
Param	None
Response	OK
Description	Clear Connected AP' s Information

Example:

Clear Connected AP' s Information

<< AT+CAP

>> OK

5.3.5 AT+BSSID - Read Connected AP' s BSSID

Com- mand	AT+BSSID
Response	+BSSID=Param
Descrip- tion	If “ERR003” is returned, it indicates that the module is not currently connected to the AP

Example:

Read Connected AP' s MAC Address

<< AT+BSSID=1063C85FCB9F

>> OK

5.3.6 AT+LIP - Read Current Local IP Address

Com- mand	AT+LIP
Response	+LIP=Param
Descrip- tion	If “0.0.0.0” is returned, it indicates that the module is not currently connected to the AP

Example:

Read Local IP Address

```
<< AT+LIP=192.168.0.224
```

```
>> OK
```

5.3.7 AT+MDNSEN - Enable/Disable MDNS Function

Command	AT+MDNSEN{=Param}
Param	0: Disable(default) 1: Enable
Response	+MDNSEN=Param

Example:

Read Whether mDNS Function is Enabled

```
<< AT+MDNSEN
```

```
>> +MDNSEN=0
```

```
>> OK
```

Enable mDNS Function

```
<< AT+MDNSEN=1
```

```
>> OK
```

5.3.8 AT+DHCP - Read/Write IP Distribution Mode

Command	AT+DHCP{=Param}
Param	0:Use static IP 1:Use dynamic IP(default)
Response	+DHCP=Param
Description	If a static IP address is used for connection, ensure that the static IP address, mask, gateway, and DNS Settings are correct. Otherwise, network communication may be interrupted

Example:

Read IP Distribution Mode

<< AT+DHCP

>> +DHCP=1

>> OK

Use static IP

<< AT+DHCP=0

>> OK

5.3.9 AT+SIP - Read/Write Static IP

Command	AT+SIP{=Param}
Param	IPV4 Address
Response	+SIP=Param
Description	This command can be used when +DHCP=0

Example:

Read Static IP Address

<< AT+SIP

>> +SIP=0.0.0.0

>> OK

Write Static IP Address as “192.168.0.23”

<< AT+SIP=192.168.0.23

>> OK

5.3.10 AT+GW - Read/Write Gateway

Command	AT+GW{=Param}
Param	IPV4 Address
Response	+GW=Param
Description	This command can be used when +DHCP=0

Example:

Read Gateway Address

<< AT+GW

>> +GW=192.168.1.1

>> OK

Write Gateway Address as “192.168.10.1”

<< AT+GW=192.168.10.1

>> OK

5.3.11 AT+MASK - Read/Write Subnet Mask

Command	AT+MASK{=Param}
Param	IPV4 Address
Response	+MASK=Param
Description	This command can be used when +DHCP=0

Example:

Read Subnet Mask

<< AT+MASK

>> +MASK=255.255.0.0

>> OK

Write Subnet Mask as “255.255.255.0”

<< AT+MASK=255.255.255.0

>> OK

5.3.12 AT+DNS - Read/Write DNS Address

Command	AT+DNS{=Param}
Param	IPV4 Address
Response	+DNS=Param
Description	This command can be used when +DHCP=0

Example:

Read DNS

<< AT+DNS

>> +DNS=0.0.0.0

>> OK

Write DNS Address as “8.8.8.8”

<< AT+DNS=8.8.8.8

>> OK

5.3.13 AT+APAC - Read/Write Automatically Connect to AP

Command	AT+APAC{=Param}
Param	0:Disable 1:Enable(default)
Response	+APAC=Param
Description	This command can be used when +ROLE=1 or 3

Example:

Read Whether Automatically Connect to AP Function is Enabled

<< AT+APAC

>> +APAC=1

>> OK

Enable Automatically Connect to AP Function

<< AT+APAC=1

>> OK

5.3.14 AT+RSSI - Read Signal Strength Between Module And AP

Command	AT+RSSI
Response	+RSSI=Param
Param	RSSI value (-99 ~ 0)
Description	The result of RSSI is 0 when disconnect from AP.

Example:

Read RSSI

<< AT+RSSI

>> +RSSI=-56

>> OK

5.3.15 AT+STAMP - Read Time Stamp

Command	AT+STAMP
Response	+STAMP=Param
Param	value (unit:second)
Description	Module needs to access the Internet,otherwise it will fail.

Example:

Read Time Stamp

<< AT+STAMP

>> +STAMP=1682319289

>> OK

5.3.16 AT+MAC - Read Wi-Fi MAC Address

Command	AT+MAC
Response	+MAC=Param
Param	Wi-Fi MAC Address(12 Bytes ASCII)
Description	MAC address can only be read , not be written

Example:

<< AT+MAC

>> +MAC=DC0D30800204

>> OK

5.3.17 AT+SCFG - Simple Config

Command	AT+SCFG=Param
Param	1:Start Simple Config 2:Start Air-Kiss Config 0:Stop Simple Config
Response	OK
Note	This command should be used with Feasy-WiFi and Airkiss APP

5.3.18 AT+WEBCFG - WEB Config

Command	AT+WEBCFG=Param
Param	1:Start WEB Config 0:Stop WEB Config
Response	OK
Description	This command can be used when +ROLE=2

Example:

Start WEB Config

<< AT+WEBCFG=1

>> OK

5.3.19 AT+WPSCFG - WPS Config

Command	AT+WPSCFG=Param
Param	1:Start WPS Config
Response	OK

Example:

Start WPS Config

<< AT+WPSCFG=1

>> OK

5.3.20 AT+LAP - Read/Write AP Mode Configuration

Command	AT+LAP{=Param1,Param2,Param3}
Param1	The SSID of the module as a AP
Param2	The password of the module as a AP
Param3	The IP address of the module as a AP
Response	+LAP=Param1, Param2, Param3
Description	If the module is configured as a AP with OPEN encryption, no need to set the Param2, such as AT+LAP=FSC-BW236-AP,192.168.1.1

Example:

Read AP Mode Configuration

<< AT+LAP

>> +LAP=FSC-BW236-AP,12345678,192.168.1.1

>> OK

Write AP Mode Configuration

<< AT+LAP=test,12345678,192.168.10.1

>> OK

5.4 TCP Command

5.4.1 AT+SOCK - Read/Write SOCKET

Command	AT+SOCK{=Param1,Param2,Param3,Param4}
Param1	Protocol Type(TCPS,TCPC,UDP,SSL)
Param2	Port of Module
Param3	Remote Address
Param4	Remote Port
Response	+SOCK=Param1, Param2, Param3, Param4
Description	The TCP SERVER is enabled after power on, default port is 9100 Param3 and Param4 can be omitted if module works as a TCP Server or a UDP

Example:

Read SOCKET Configuration

<< AT+SOCK

>> +SOCK=TCPS,9100,0.0.0.0,0

>> OK

Module works as **TCP Server**, local port is 8080

```
<< AT+SOCK=TCPS,8080
```

```
>> OK
```

Module works as **TCP client**, local port is 8080,remote server address is “192.168.0.224”
 ,remote server port is 6000

```
<< AT+SOCK=TCPC,8080,192.168.0.224,6000
```

```
>> OK
```

Module works as **UDP**,local port is 4000

```
<< AT+SOCK=UDP,4000
```

```
>> OK
```

5.4.2 AT+WLANC - Start SOCKET/MQTT

Command	AT+WLANC=Param
Param	3:Connection with TCP/UDP/SSL 4:Connection with MQTT or cloud platform 5:Connection with WEB Socket
Response	OK
Description	This command can only be used after the SOCKET or MQTT configuration is completed

5.4.3 AT+MAXCON - Read/Write Max Connections As TCP Server

Command	AT+MAXCON=Param
Param	Max Connections
Response	+MAXCON=Param
Description	Default Max Connections is 3

Example:

Read Max Connections

```
<< AT+MAXCON
```

```
>> +MAXCON=3
```

```
>> OK
```

Write Max Connections as 1

```
<< AT+MAXCON=1
```

```
>> OK
```

5.4.4 AT+WFSEND - Send SOCKET Data to Remote Device

Command	AT+WFSEND=Param1,Param2,Param3
Param1	TCP/UDP Connection ID
Param2	Payload length (1~999)
Param3	Payload (1~999 Bytes UTF8)
Response	OK
Description	When the module is used as TCP server, it can be connected by 3 remote clients and connection ID is 0,1,2; When the module is used as TCP client, the ID is 3; When the module is UDP, the ID is 4. The connection ID will vary with the MAXCON setting, such as the MAXCON is 6, the ID as TCP Server is 0 ~ 5, and the ID as the TCP Client is 6, the ID as UDP is 7

Example:

Send data to **TCP Client**

```
<< AT+WFSEND=0,3,123
```

```
>> OK
```

Send data to **TCP Server**

<< AT+WFSEND=3,3,123

>> OK

Send data to **UDP**

<< AT+WFSEND=4,3,123

>> OK

5.4.5 AT+CLOSE - Close Connection as TCP client

Command	AT+CLOSE
Response	OK
Description	This command can be used to disconnect from a remote TCP Server ,if module works as a TCP Client

Example:

<< AT+CLOSE

>> OK

5.5 WEBSOCKET Command

5.5.1 AT+WEBSOCK - Read/Write WEBSOCKET Address

Command	AT+WEBSOCK=Param1,Param2
Param1	WSC : Module works as Client WSS : Module works as Server
Param2	Remote Server Address if Module works as Client Local IP Address if Module works as Server
Response	+WEBSOCK=Param1,Param2
Description	Param2 should start with ws:// or wss:// ,

Example:

Module works as client

```
<< AT+WEBSOCK=WSC,ws://192.168.0.188:443/read
```

```
>> OK
```

Example:

Module works as server

```
<< AT+WEBSOCK=WSS,ws://192.168.0.144
```

```
>> OK
```

Note:

- **PORT** configuration can be omitted.80 is default for **ws**,433 is default for **wss**
- WEBSOCKET and TCP can' t be used at the same time.

5.5.2 AT+WSEND - Send Websocket Data

Command	AT+WSEND=Param1{,Param2},Param3,Param4
Param1	WSC : Module works as Client WSS : Module works as Server
Param2	Specify the client ID. This parameter is only required if the module works as Server
Param3	Payload length
Param4	Payload
Response	OK
Description	Module supports one Client by default if works as Server . Therefore, Param2 is 1 when sending data

Example:

Module sends data as **Client**

```
<< AT+WSEND=WSC,10,0123456789
```

```
>> OK
```

Example:

Module sends data as **Server**

```
<< AT+WSEND=WSS,1,10,0123456789
```

```
>> OK
```

5.5.3 AT+WSCLS - Close Websocket

Command	AT+WSCLS
Response	OK
Description	Close Connection With Websocket

Example:

Close Websocket

<< AT+WSCLS

>> OK

5.5.4 AT+WSSTAT - Read Websocket Status

Command	AT+WSSTAT
Response	+WSSTAT=Param1,Param2
Description	0: uninitialized 1: ready 2: connecting 3: connected Param1: Module' s websocket status when works as Client Param2: Module' s websocket status when works as Server

Example:

Read Websocket Status

<< AT+WSSTAT

>> +WSSTAT=3,0

>> OK

5.6 HTTP Command

5.6.1 AT+HTTP - Access the HTTP Server

Command	AT+HTTP=Param1,Param2,Param3{,Param4}
Param1	HTTP Request Method, only support GET and POST
Param2	HTTP server' s address
Param3	HTTP server' s URI
Param4	Resume breakpoint to support This Parameter can be omitted. Format is “Range:bytes=starting byte-ending byte”
Response	OK
Description	AT+HTTP is used to access HTTP server AT+HTTPS is used to access HTTPS server The default port of HTTP server is 80, default port of HTTPS server is 443 Param2 can be set like this “x.x.x.x:port” ,if port of server need to be specified

Example:

Access Github,and read all the data

```
<< AT+HTTP=GET,www.github.com,/
```

```
>> OK
```

```
>> {Data Content}
```

Access Github,and read bytes from the 3rd to the 10th

```
<< AT+HTTP=GET,www.github.com/,Range:bytes=3-10
```

```
>> OK
```

```
>> {Data Content}
```

Access HTTPS Server with port **778** to download file named “**test.bin**” in the “**OTA**” directory

```
<< AT+HTTPS=GET,192.168.0.179:778,/OTA/test.bin
```

```
>> OK
```

```
>> {Data Content}
```

POST param1=test_data1¶m2=test_data2 to <http://httpbin.org/post>

```
<< AT+HTTP=POST,httpbin.org,/post,param1=test_data1&param2=test_data2
```

```
>> OK
```

```
>> {Data Content}
```

Note:

- “<http://httpbin.org>” is available for testing **HTTP**
-

5.7 MQTT Command

5.7.1 AT+BROKER - Read/Write MQTT broker

Command	AT+BROKER{=Param}
Param	MQTT server address
Response	+BROKER=Param
Description	“gpssensor.ddns.net” is available for testing MQTT

Example:

Read MQTT broker

```
<< AT+BROKER
```

```
>> +BROKER=gpssensor.ddns.net
```

```
>> OK
```

Write MQTT broker

```
<< AT+BROKER=gpssensor.ddns.net
```

```
>> OK
```

5.7.2 AT+CLIENTID - Read/Write MQTT Client ID

Command	AT+CLIENTID{=Param}
Param	MQTT Client ID
Response	+CLIENTID=Param

Example:

Read MQTT Client ID

```
<< AT+CLIENTID
```

```
>> +CLIENTID=user
```

```
>> OK
```

Write MQTT Client ID

```
<< AT+CLIENTID=447a74ab3e60494e8c97dad36b00399b
```

```
>> OK
```

5.7.3 AT+USERNAME - Read/Write MQTT USERNAME

Command	AT+USERNAME{=Param}
Param	MQTT USERNAME
Response	+USERNAME=Param

Example:

Read MQTT USERNAME

```
<< AT+USERNAME
```

```
>> +USERNAME=admin
```

```
>> OK
```

Write MQTT USERNAME

```
<< AT+USERNAME=admin
```

```
>> OK
```

5.7.4 AT+MQTTPWD - Read/Write MQTT password

Command	AT+MQTTPWD{=Param}
Param	MQTT MQTTPWD
Response	+MQTTPWD=Param

Example:

Read MQTT password

```
<< AT+MQTTPWD
```

```
>> +MQTTPWD=12345678
```

```
>> OK
```

Write MQTT password

```
<< AT+MQTTPWD=12345678
```

```
>> OK
```

5.7.5 AT+SUBTPC - Read/Subscribe MQTT Topic

Command	AT+SUBTPC{=Param1,Param2}
Param1	Topic
Param2	QOS, only can be 0,1,2
Response	+SUBTPC=Param1,Param2

Example:

Read MQTT TOPIC

```
<< AT+SUBTPC
```

```
>> +SUBTPC=/fsc/bw236/get,0
```

```
>> OK
```

Write MQTT TOPIC

```
<< AT+SUBTPC=/fsc/bw236/test,2
```

```
>> OK
```

Note:

- The command will return an error if the same topic is subscribed repeatedly
 - Maximum of five different subscribed topics is 5
-

5.7.6 AT+UNSUBTPC - Unsubscribe Specify MQTT Topic

Command	AT+UNSUBTPC=Param
Param	Specify the topic to be unsubscribed
Response	OK
Description	There is no need to specify a QoS value when unsubscribes

Example:

```
<< AT+UNSUBTPC=/fsc/bw236/get
```

```
>> OK
```

5.7.7 AT+UNSUBALL - Unsubscribe All MQTT Topics

Command	AT+UNSUBALL
Response	OK

Example:

```
<< AT+UNSUBALL
```

```
>> OK
```

5.7.8 AT+MQTTSEND - Send MQTT Data

Command	AT+MQTTSEND=Param1,Param2,Param3,Param4
Param1	Publish Topic
Param2	QOS(0,1,2)
Param3	Payload length
Param4	Payload
Response	OK

Example:

```
<< AT+MQTTSEND=fsc/bw236/get,0,3,abc
```

```
>> OK
```

5.7.9 AT+MQTTMODE - Read/Write MQTT Mode

Command	AT+MQTTMODE{=Param}
Param	0: Connect to general MQTT Server(default) 1: Connect to Ali Cloud Platform 2: Connect to QCloud Platform(Tencent)
Response	OK
Description	Module connects to different cloud platforms by switching MQTT modes

Example:

```
<< AT+MQTTMODE
>> +MQTTMODE=0
>> OK
```

5.7.10 AT+MQTTTS - Enable/Disable MQTT with SSL/TLS

Command	AT+MQTTTS{=Param}
Param	0: Disable(default) 1: Enable
Response	+MQTTTS=Param

Example:

Read whether SSL/TLS is enabled

```
<< AT+MQTTTS
>> +MQTTTS=0
```

>> OK

Enable SSL/TLS for MQTT

<< AT+MQTTTS=1

>> OK

5.7.11 AT+MQTTPORT - Read/Write MQTT Port

Command	AT+MQTTPORT{=Param}
Param	MQTT port, default is 1883
Response	+MQTTPORT=Param
Description	Based on the actual server port

Example:

Read MQTT Port

<< AT+MQTTPORT

>> +MQTTPORT=1883

>> OK

Write MQTT Port as 8883

<< AT+MQTTPORT=8883

>> OK

5.7.12 AT+MQTTKAI - Read/Write MQTT Keepalive

Command	AT+MQTTKAI{=Param}
Param	MQTT Keepalive time: uint is second, default value is 60
Response	+MQTTKAI=Param

Example:

Read MQTT Keepalive

```
<< AT+MQTTKAI
```

```
>> +MQTTKAI=60
```

```
>> OK
```

Write MQTT Keepalive as 300 seconds

```
<< AT+MQTTKAI=300
```

```
>> OK
```

Note:

- Set the value based on the actual platform usage restrictions.
 - General platforms, such as Alicloud, require an MQTT keepalive period of 30 to 1200 seconds
 - If module is disconnected unexpectedly more than {keepalive period * 1.5}, the MQTT server will automatically disconnect module
-

5.7.13 AT+MQTTVER - Read/Write MQTT Version

Command	AT+MQTTVER{=Param}
Param	MQTT Verison(3 or 4,default is 3)
Response	+MQTTVER=Param
Note	

Example:

Read MQTT Version

```
<< AT+MQTTVER
```

```
>> +MQTTVER=3
```

```
>> OK
```

Use MQTT Version as 3

```
<< AT+MQTTVER=3
```

```
>> OK
```

5.7.14 AT+MQTTCLS - Close MQTT Connection

Command	AT+MQTTCLS
Response	OK

Example:

```
<< AT+MQTTCLS
```

```
>> OK
```

5.8 Cloud Platform Command

5.8.1 AT+DEVNAME - Read/Write Device Name

Command	AT+DEVNAME{=Param}
Param	Device Name
Response	+DEVNAME=Param

Example:

Read Device Name

```
<< AT+DEVNAME
```

```
>> +DEVNAME=printer
```

```
>> OK
```

Write Device Name

```
<< AT+DEVNAME=printer
```

```
>> OK
```

5.8.2 AT+PROKEY - Read/Write Product Key

Command	AT+PROKEY{=Param}
Param	Product Key
Response	+PROKEY=Param

Example:

Read Product Key

```
<< AT+PROKEY
```

```
>> +PROKEY=a1jdkjfuh
```

```
>> OK
```

Write Product Key

```
<< AT+PROKEY=a1jdkjfuh
```

```
>> OK
```

5.8.3 AT+DEVSECRET - Read/Write Device Secret

Command	AT+DEVSECRET{=Param}
Param	Device Secret
Response	+DEVSECRET=Param

Example:

Read Device Secret

```
<< AT+DEVSECRET
```

```
>> +DEVSECRET=15kjdfydfhnflh
```

```
>> OK
```

Write Device Secret

```
<< AT+DEVSECRET=15kjdfydfhnflh
```

```
>> OK
```

5.9 EAP Command

5.9.1 AT+EAPEN - Read/Write EAP enterprise encryption

Command	AT+EAPEN{=Param}
Param1	1 Enable EAP enterprise encryption 0 Disable EAP enterprise encryption
Response	+EAPEN=Param
Description	Switch mode, Only take effect after reboot

Example:

```
<< AT+EAPEN=1
```

```
>> OK
```

5.9.2 AT+EAPMODE - Read/Write EAP encryption

Command	AT+EAPMODE{=Param}
Param1	1 tls 2 peap 3 ttls
Response	+EAPMODE=Param
Description	Switch mode, Only take effect after reboot

Example:

Set the encryption mode to peap

```
<< AT+EAPMODE=2
```

>> OK

5.9.3 AT+EAPCFG - Read/Write EAP connection parameters

Command	AT+EAPCFG{=Param1,Param2,Param3,Param4}
Param1	SSID
Param2	Username
Param3	Password
Param4	Identity
Response	+EAPCFG=Param1,Param2,Param3,Param4
Description	Module will automatically connect to AP after setup

Example:

<< AT+EAPCFG=Feasycom,test,12345678,test

>> OK

5.10 The Firmware Update(OTA)

5.10.1 AT+OTA - Remote OTA

Command	AT+OTA=Param
Param	Name of the firmware to be upgraded
Response	OK
Description	The firmware name is provided by the engineering or technical support personnel The module will return \$OTA=1 after a successful upgrade

Example:

<< AT+OTA=Feasycom_V429

>> OK

>> \$OTA=1

Note:

- It's best not to operate other commands or functions during the upgrade. Otherwise, the upgrade may fail or cause unexpected situations
-

Chapter 6

Events Table

6.1 MQTT Indication

6.1.1 +MQTTSTAT - MQTT Status

Format	+MQTTSTAT=Param
Param	(0) uninitialized (1) ready (2) connecting (3) connected

6.1.2 +MQTTDATA - MQTT Received Data

Format	+MQTTDATA=Param1,Param2,Param3
Param1	Topic
Param2	Payload length
Param3	Payload

Example: Receive data “1234567890” from MQTT Server

```
>> +MQTTDATA=/fsc/bw236/get,10,1234567890
```

6.2 WEBSOCKET Indication

6.2.1 +WSSTAT - WEBSOCKET 状态

Format	+WSSTAT=Param1,Param2
Param1	(0) uninitialized (1) ready (2) connecting (3) connected
Param2	(0) uninitialized (1) ready (2) connecting (3) connected

6.3 SSL Indication

6.3.1 +SSLSTAT - SSL Client Status

Format	+SSLSTAT=Param
Param	(0) uninitialized (1) ready (2) connecting (3) connected

6.3.2 +SSLDATA - Receive SSL Data

Format	+SSLDATA=Param1,Param2
Param1	Payload length
Param2	Payload

Example: Receive data “1234567890” from SSL Server

>> +SSLDATA=10,1234567890

6.4 SOCKET Indication

6.4.1 +WFDATA - Receive SOCKET Data

Format	+WFDATA=Param1,Param2,Param3
Param1	TCP/UDP Connection ID
Param2	Payload length
Param3	Payload

Example: Receive data “1234567890” from remote SOCKET device

```
>> +WFDATA=3,10,1234567890
```

Note:

- For details about the connection ID, see the **AT+WFSEND** command
-

6.5 GATT Indication

6.5.1 +GATTSTAT - GATT Status

Format	+GATTSTAT=Param
Param	(0) uninitialized (1) ready (2) connecting (3) connected

6.5.2 +GATTDATA - Receive GATT Data

Format	+GATTDATA=Param1,Param2
Param1	Payload length
Param2	Payload

Example: Receive GATT data “1234567890” from remote device


```
>> +GATTDATA=10,1234567890
```

Chapter 7

Application Scenarios

Shenzhen Feasycom Co., Ltd.

7.1 TCP Server Application



Specific Command Process Description

1、Switch to STA Mode.

<< AT+ROLE=1

>> OK

2、 Connect to AP

```
<< AT+RAP=ssid,password  
>> OK
```

3、 Query the IP address to check whether AP is connected

```
<< AT+LIP  
>> +LIP=192.168.0.87
```

4、 Set module as **TCP Server** with port 9100

```
<< AT+SOCK=TCPS,9100  
>> OK
```

5、 Start TCP Server

```
<< AT+WLANC=3  
>> OK
```

6、 Send Data

```
<< AT+WFSEND=0,3,123  
>> OK
```


7、 Received Data

```
<< +WFDATA=0,10,1234567890
```

Note:

- **Throughput Mode** should be set at the beginning
 - The module is in STA mode by default. Step 1 can be omitted
 - The module enables a TCP server with port 9100 by default. Step 4 and 5 can be omitted
-

7.2 TCP Client Application



Specific Command Process Description

- 1、Switch to STA mode

<< AT+ROLE=1

>> OK

2、Connect to AP

<< AT+RAP=ssid,password

>> OK

3、Query the IP address to check whether AP is connected

<< AT+LIP

>> +LIP=192.168.0.87

4、Set module as **TCP Client** with port 9100,configure the IP and port of the remote server

<< AT+SOCK=TCPC,9100,192.168.0.100,6000

>> OK

5、Start TCP Client

<< AT+WLANC=3

>> OK

6、Send Data

<< AT+WFSEND=3,3,123

>> OK

7、Received Data


<< +WFDATA=3,10,1234567890

Note:

- **Throughput Mode** should be set at the beginning

- The module is in STA mode by default. Step 1 can be omitted

7.3 UDP Application



Specific Command Process Description

1、 Switch to STA mode

<< AT+ROLE=1

>> OK

2、 Connect to AP

<< AT+RAP=ssid,password

>> OK

3、 Query the IP address to check whether the hotspot is connected

<< AT+LIP

>> +LIP=192.168.0.87

4、 Set module as **UDP**

<< AT+SOCK=UDP,4000

>> OK

5、 Start UDP

<< AT+WLANC=3

>> OK

6、 Send Data

<< AT+WSEND=4,3,123

>> OK

7、 Received Data


<< +WFDATA=4,10,1234567890

Note:

- **Throughput Mode** should be set at the beginning
-

Shenzhen Feasycom Co., Ltd.

7.4 MQTT Application



Specific Command Process Description

1、 Switch to STA mode

<< AT+ROLE=1

>> OK

2、 Connect to AP

<< AT+RAP=ssid,password

>> OK

3、 Query the IP address to check whether AP is connected

<< AT+LIP

>> +LIP=192.168.0.87

4、 Set Broker

<< AT+BROKER=gpssensor.ddns.net

>> OK

5、 Set MQTT Port

<< AT+MQTTPORT=1883

>> OK

6、 Set Client ID

<< AT+CLIENTID=BW236

>> OK

7、 Set Username

<< AT+USERNAME=admin

>> OK

8、 Set Password

<< AT+MQTTPWD=12345678

>> OK

9、Subscribe MQTT Topic

<< AT+SUBTPC=topic,0

>> OK

10、Start MQTT

<< AT+WLANC=4

>> OK

11、Receive Data

<< +MQTTDATA=topic,10,1234567890


12、Send Data

<< AT+MQTTSEND=topic,0,3,abc

Note:

- Need to subscribe to the topic before initiating a connection
 - **MQTTMODE** should be set to **0**
-

7.5 Ali Cloud Platform Application



Specific Command Process Description

1、 Switch to STA mode

<< AT+ROLE=1

>> OK

2、 Connect to AP

<< AT+RAP=ssid,password

>> OK

3、 Query the IP address to check whether AP is connected

<< AT+LIP

>> +LIP=192.168.0.87

5、 Set MQTT mode to connect Ali Cloud

<< AT+MQTTMODE=1

>> OK

6、 Set Device Name

<< AT+DEVNAME=name

>> OK

7、 Set ProductKey

<< AT+PROKEY=key

>> OK

8、 Set DeviceSecret

<< AT+DEVSECRET=secret

>> OK

9、Subscribe

```
<< AT+SUBTPC=topic,qos  
>> OK
```

10、Initiates a connection

```
<< AT+WLANC=4  
>> OK
```

11、Send Data

```
<< AT+MQTTSEND=topic,3,abc  
>> OK
```

12、Receive Data

```
<< +MQTTDATA=topic,10,1234567890
```

Note:

- Before establishing a connection ,must subscribe at least one topic
 - **Throughput Mode** should be set at the beginning
-

7.6 Switch Throughput Mode to Command Mode

Specific Instruction Process Description

When **Throughput Mode** is enabled, any command is transmitted as data

The module provides a way to exit the **Throughput Mode** to send command

```
<< +++  
<< a  
>> a
```

>> +ok

Note:

- The above data format is different from the normal AT command which ends with **<CR><LF>**
 - The above data does not have any terminator attached
-

7.7 Network Configuration and OTA

7.7.1 OTA by AT Command

Specific Instruction Process Description

1、 Switch to STA Mode.

<< AT+ROLE=1

>> OK

2、 Connect to AP

<< AT+RAP=ssid,password

>> OK

3、 Query the IP address to check whether AP is connected

<< AT+LIP

>> +LIP=192.168.0.87

4、 The upgrade starts. The firmware name is provided by the engineer or related personnel

<< AT+OTA=Feasycom_V555

>> OK

>> \$OTA=1

Note:

- The firmware is stored in the specific server and the upgrade mode can be changed as required by customers
 - Module needs to access the Internet, otherwise it will fail
-


7.7.2 OTA by FeasyWiFi APP

Specific Instruction Process Description

- 1、Download FeasyWiFi APP from **APP STORE** or **GOOGLE PLAY**
- 2、Enter the APP interface , search and connect to the target module

No SIM 20:11    		
Sort	Setting	Filter
	FSC-BW236-LE	
	mac: DC:0D:30:60:01:0E	RSSI:-60
	Unknown	
	mac: FF:C3:7E:69:FE:01	RSSI:-57
	Unknown	
	mac: FB:28:A6:63:1B:1F	RSSI:-59
	Unknown	
	mac: 77:61:35:AE:03:EF	RSSI:-61
	Unknown	
	mac: 2B:E0:8C:FE:8E:34	RSSI:-68
	FSC-BW236-LE	
	mac: DC:0D:30:60:EE:CF	RSSI:-63
	Unknown	
	mac: DC:23:4E:F2:DE:08	RSSI:-60
	Unknown	
	mac: 07:CB:90:8C:BD:7E	RSSI:-62
	Unknown	
	mac: 11:6B:05:6B:76:B3	RSSI:-74
	头条	
	mac: AC:23:3F:20:96:E3	RSSI:-67
	Unknown	
	mac: DC:0D:30:00:07:90	RSSI:-68
	FSC-BT618	
Setting About		

2、 After correct connection, it will jump to the following interface:



3、 Enter the AP' s SSID and password on the **BLE Network** page, then click the **Start Network Config** button

Shenzhen Feasycom Co., Ltd.

20:12



 Back

BLE network

SSID:

test

Password:

12345678

DHCP

☒

Start network config



+

-

%

/

1

2

3

4

5

6

7

8

9

0



,

:

.

- 4、Return to the previous page after the network configuration is successful,
choose **OTA upgrade**, enter firmware name then click the **Upgrade** button

Shenzhen Feasycom Co., Ltd.

No SIM20:14

< Back

OTA upgrade

Firmware name:

Please enter the firmware name

Upgrade

Module IP:

192.168.0.19

Query IP

Module version:

FSC-BW236,V4.2.8

Query Version

Restore factory setting

Note:

- Module needs to access the Internet, otherwise it will fail
-

Shenzhen Feasycom Co., Ltd.

Chapter 8

Appendix

8.1 Download PDF Document

download PDF Document

Shenzhen Feasycom Co., Ltd.